Alphabetical index

Δ	A /C
A	A/C

•	
Air conditioning filter	514
ABS	246
ACCESSORY mode	159
Active torque control	
AWD mode	246
AFS	194
Adaptive front-lighting system	194
Air conditioning filter	514
Air conditioning system*	294
Automatic air conditioning	
system*	294

Airbags

Airbag operating conditions	IZU
Airbag precautions for your	
child	124
Airbag warning light	558
Curtain shield airbag operating	
conditions	120
Curtain shield airbag	
precautions	124
Front passenger occupant	
classification system	129
General airbag precautions	124
Locations of airbags	116
Modification and disposal of	
airbags	128
Proper driving posture114	, 124
Side airbag operating	
conditions	120
Side airbag precautions	124
SRS airbags	

Alarm	110
Anti-lock brake system	246
Armrest	438
Audio input	357
Audio system*	
Audio input	357
AUX port	357
CD player/changer	317
iPod	337
MP3/WMA disc	327
Optimal use	354
Portable audio device	
Radio	307
Steering wheel audio switch	359
USB memory	
USB port	

Automatic air conditioning system	
Air conditioning filter	. 514
Air conditioning system*	294
Automatic headlight leveling	
system	. 196
Automatic high beam system	197
Automatic light control system	191
Automatic transmission	
Automatic transmission	.165
If the shift lever cannot be	
shifted from P	603
S mode	167
AUX port	357

 $[\]ensuremath{^*}$: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

3	Back door	
	Back door	.55
	Wireless remote control	.48
	Back-up lights	
	Wattage6	529
	Battery	
	Checking	195
	If the vehicle has a	
	discharged battery6	800
	Preparing and checking	
	before winter	
	Bluetooth [®] audio [*]	362
	Bluetooth® phone*	382
	Brake	
	Fluid6	525
	Parking brake	171
	Brake assist	246

Break-in tips......151

Care	
Exterior	464
Interior	468
Seat belts	469
Cargo hooks	441
CD changer*	
CD	317
MP3	327
WMA disc	327
CD player*	317
Chains	269

Child restraint system

Booster seats, definition	134
Booster seats, installation	141
Convertible seats, definition	134
Convertible seats, installation	141
Front passenger occupant	
classification system	129
Infant seats, definition	134
Infant seats, installation	141
Installing CRS with LATCH	
anchors	139
Installing CRS with seat belts	141
Installing CRS with top tether	
straps	145

Child safety

Airbag precautions	124
Back door precautions	61
Battery precautions496	, 610
Child restraint system	134
Child-protectors	53
How your child should wear	
the seat belt	86
Installing child restraints	138
Moon roof precautions	103
Power window lock switch	97
Power window precautions	99
Removed electronic key battery	
precautions	518
Seat belt comfort guide	83
Seat belt extender precautions	89
Seat belt precautions	87
Seat heater precautions	.437
Child-protectors	53

 $[\]ensuremath{^*}$: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

Cleaning	
Exterior	464
Interior	468
Seat belts	469
Clock*	430
Coat hooks	439
Compass	452
Condenser	493
Console box	424
Cooling system	
Engine overheating	611
Cornering assist sensors	235
Cruise control	
Cruise control	217
Dynamic radar cruise control	222
Cup holders	422
Curtain shield airbags	116
Customizable features	645

Daytime running light system	195
Defogger*	
Rear window	301
Side mirrors	94
Dimensions	618
Dinghy towing	291
Display	
Multi-information display	180
Trip information	183
Warning message	568
Do-it-yourself maintenance	478
Door courtesy lights	
Door courtesy lights	416
Wattage	629
Doorlock	
Back door	55
Side door	52
Wireless remote control	48
Door pockets	421
Doors	
Back door	55
Door windows	97
Door lock35, 4	48, 52
Power back door	55
Side door	52
Side mirrors	94
Driver's seat belt reminder light.	560
Driving	
Break-in tips	151
Correct posture	114
Utility vehicle precautions	260
Procedures	150
Winter driving tips	269
Driving position memory	75

Electric power steering246
Electronic features control180
Electronic key
If the electronic key does not
operate properly605
Emergency flasher switch 546
Emergency, in case of
If the electronic key does not
operate properly605
If the engine will not start601
If the shift lever cannot be
shifted from P603
If the vehicle has a
discharged battery608
If a warning buzzer sounds557
If a warning light turns on557
If a warning message is
displayed568
If you have a flat tire587
If you lose your keys604
If you think something is
wrong555
If your vehicle becomes stuck614
If your vehicle has to be stopped
in an emergency615
If your vehicle needs to be
towed547
If your vehicle overheats611

Engine	
Accessory mode	159
Compartment	484
Engine switch	159
Hood	481
How to start the engine	159
Identification number	619
If the engine will not start	601
Ignition switch	159
Overheating	611
Engine compartment cover	485
Engine coolant	
Capacity	623
Checking	491
Preparing and checking	
before winter	269
Engine coolant temperature	
gauge	173
Engine immobilizer system	108
Engine oil	
Capacity	621
Checking	487
Preparing and checking	
before winter	269
EPS	
Event data recorder	24

 $[\]ensuremath{^*}$: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

F	Floor mat	440	G	Garage door opene
	Fluid			Gauges
	Brake	625		Glove box
	Washer	498		
	Fog lights		Н	Hands-free system fo
	Switch	204		mobile phone*
	Wattage	629		Hazard lights switch
	Footwell lights	416		Head-up display
	Front fog lights			Head restraints
	Switch	204		Adjustment
	Wattage	629		Headlight aim
	Front passenger occupant			Headlight cleaner
	classification system	129		Headlights
	Front passenger's seat belt			Discharge headlig
	reminder light	560		precautions
	Front seats			Replacing light bu
	Adjustment	67		Switch
	Driver's seat position memor	y75		Wattage
	Flattening seatbacks	67		Head-up display
	Front side marker light			Heaters
	Replacing light bulbs	532		Seat heaters
	Wattage	629		Side mirrors*
	Front turn signal lights			Hill-start assist contr
	Replacing light bulbs	532		Hood
	Wattage	629		Hooks
	Fuel			Cargo
	Capacity	620		Coat
	Fuel gauge	173		HUD
	Fuel pump shut off system	556		Horn
	Information	630		
	Refueling	104		
	Туре	630		
	Fuel door	104		
	Fuel filler door	104		
	Fuel pump shut off system	556		
	Fuses	519		

,	Garage door opener	446
	Gauges	173
	Glove box	420
ł	Hands-free system for	
	mobile phone*	382
	Hazard lights switch	546
	Head-up display	186
	Head restraints	
	Adjustment	80
	Headlight aim	530
	Headlight cleaner	216
	Headlights	
	Discharge headlight	
	precautions	543
	Replacing light bulbs	532
	Switch	191
	Wattage	629
	Head-up display	186
	Heaters	
	Seat heaters	436
	Side mirrors*	301
	Hill-start assist control	253
	Hood	481
	Hooks	
	Cargo	441
	Coat	439
	HUD	186
	Horn	172

I/M test477
Identification
Engine619
Vehicle619
Ignition switch159
Illuminated entry system416
Indicator lights175
Initialization
Items to initialize654
Inside rear view mirror92
Interior lights
Interior lights416
Switch417
Wattage629

Keyless entry	48
Keys	
Electronic key	30
Engine switch15	59
If the electronic key does not	
operate properly60)5
If you lose your keys60)4
lgnition switch15	59
Key number	30
Keyless entry	48
Keys	30
Mechanical key	.31
Wireless remote control key	48

J Jack Positioning

 $[\]ensuremath{^*}$: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

Light bulbs	Maintenance
Replacing532	Do-it-yourself maintenance 478
Wattage629	General maintenance473
Lights	Maintenance data618
Door courtesy lights416	Maintenance requirements 471
Emergency flasher switch546	Maintenance data471
Fog light switch204	Meter
Hazard lights switch546	Instrument panel light control 174
Headlight switch191	Meters173
Interior light switch417	Mirrors
Luggage compartment light58	Inside rear view mirror92
Outer foot lights416	Side mirror heaters*301
Overhead courtesy light416	Side mirrors94
Personal light switch417	Vanity mirrors429
Replacing light bulbs532	Moon roof100
Scuff lights416	MP3 disc327
Shift lever light416	Multi-information display180
Turn signal lever169	
Vanity lights429	Noise from under vehicle22
Wattage629	
Load capacity268	Odometer173
Lock steering column162	Oil
Luggage compartment lights	Engine oil
Switch58	Opener
Wattage629	Back door
Luggage cover443	Fuel filler door104
	Hood481
	701

	Outer foot lights	R	Radar
	Outer foot lights416		Radia
	Wattage629		Radio
	Outside rear view mirrors		Rears
	Adjusting and folding94		Fol
	Mirror position memory75		Sea
	Outside temperature display*431		Rear t
	Overhead console426		Re
	Overhead courtesy lights		W
	Overhead courtesy lights416		Rear v
	Wattage629		Сс
	Overheating, Engine611		Rear v
			Rearv
)	Parking assist sensors235		Rear v
	Parking brake171		Remo
	Parking lights		Repla
	Replacing light bulbs532		Ele
	Switch191		Fus
	Wattage629		Lig
	PCS255		Tire
	Personal lights		Wi
	Switch417		b
	Power back door 55		Roof I
	Power outlet433		Repor
	Power windows97		U.S.
	Pre-collision system255		

Radar cruise control	222
Radiator	493
Radio	307
Rear seat	
Folding down	71
Seat adjustment	71
Rear turn signal lights	
Replacing light bulbs	533
Wattage	629
Rear view mirror	
Compass	452
Rear view monitor system	242
Rear window defogger*	301
Rear window wiper*	214
Remote Touch*	
Replacing	
Electronic key battery	517
Fuses	519
Light bulbs	532
Tires	587
Wireless remote control	
battery	517
Roof luggage carrier	264
Reporting safety defects for	
U.S. owners	656

^{*:} For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

Safety Connect	456
Scuff lights	
Seat belts	
Adjusting the seat belt	83
Automatic locking retractor	
Child restraint system	
installation	138
Cleaning and maintaining	
the seat belts4	169
Emergency locking retractor	
How to wear your seat belt	
How your child should wear	
the seat belt	86
Pregnant women,	
proper seat belt use	85
Reminder light	
Seat belt extenders	86
Seat belt pretensioners	
Seat heaters	436
Seats	
Adjustment6	7, 71
Adjustment	
precautions70	, 73
Child seats/child restraint	
system installation	138
Cleaning4	
Head restraint	
Properly sitting in the seat	114
Seat heaters	136

Seat position memory......75

Service reminder indicators	175
Shift lever	
Automatic transmission	165
If the shift lever cannot be	
shifted from P	603
Shift lever light	416
Shift lock system	
Side airbags	116
Side marker lights	
Switch	191
Side mirror	
Adjusting and folding	94
Mirror position memory	
Smart access system with	
push-button start	
Entry function	35
Starting the engine	159
"SOS" button	

Spare tire	
Inflation pressure	508
Storage location	.587
Spark plug	623
Specifications	618
Speedometer	173
Steering wheel	
Adjustment	90
Audio switches*	.359
Power easy access system	77
Steering wheel position	
memory	
Storage feature	419
Stuck vehicle	
If your vehicle becomes stuck	614
Sun visors	428
Sunshades	
Roof	101

Switch

Display contrast adjustment	
switch	186
Display position adjustment	
switch	186
ECT SNOW switch	166
Emergency flasher switch	546
Engine switch	159
ENTER switch	18C
Fog light switch	204
Hazard light switch	546
Head-up display main switch	
button	186
Ignition switch	159
Light switches	191
Menu switch	180
Power back door opener	55
Power door lock switch	52
Power window switch	97
Window lock switch	97
Wiper and washer switch	207

 $[\]ensuremath{^*}$: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

Tachometer173
Tail lights
Replacing light bulbs533
Switch191
Wattage629
Theft deterrent system
Alarm110
Engine immobilizer system108
Tire inflation pressure508
Tire information
Glossary639
Size636
Tire identification number635
Uniform tire quality grading637
Tires
Chains269
Checking499
If you have a flat tire587
Inflation pressure508
Inflation pressure sensor500
Information633
Replacing587
Rotating tires499
Size626
Snow tires269
Spare tire588
Tire pressure warning
system500, 560
Tools587
Total load capacity268
II

Towing	
Emergency towing	548
Trailer towing	273
TRAC	246
Traction control	246
Trip information display	180
Trip meter	173
Turn signal lights	
Replacing light bulbs	532
Switch	
Wattage	629
USB port*	345

Vanity lights		Warning messages	
Vanity lights	429	Adaptive front-lighting syster	n 570
Wattage	629	Automatic transmission fluid.	570
Vanity mirrors	429	Anti-lock brake system	570
VDIM	246	AWD system569, 57	70, 574
Vehicle dynamics integr	ated	Brake lamp system	570
management	246	Brake system	568
Vehicle identification nu	mber619	Dynamic radar cruise	
Vehicle stability control.	246	control system57	70, 574
VSC	246	Electric power steering	570
		Engine oil maintenance	574
Warning buzzers		Engine oil pressure	569
Brake system	557	Engine overheat	574
Open door		Headlight leveling	570
Seat belt reminder		Hood	574
Warning lights		Intuitive parking assist57	74, 570
Anti-lock brake syster	n558	Low fuel	574
Brake assist system		Moon roof	574
Brake system		Open door	574
Charging system		Parking brake	574
Electric power steerin		Pre-collision system 570, 574	
Electronic engine con	trol	Smart access system with	
system	558	push-button start	579
Low fuel level		SRS airbags	
Low tire pressure	560	Steering lock	
Malfunction indicator	lamp558	Washer fluid	574
Master warning light	560		
Open door	560		
Pre-collision system	558		
Pretensioners	558		
Seat belt reminder lig	nt560		

^{*:} For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

Washer	
Checking	498
Preparing and checking	
before winter	269
Switch	207
Washing and waxing	464
Weight	
Load limits	268
Weight	618
Wheels	512
Window glasses	97
Window lock switch	97
Windows	
Power windows	97
Rear window defogger*	301
Washer	207
Windshield wiper de-icer*	302
Windshield wipers	207
Wireless remote control key	
Replacing the battery	517
WMA disc	327

^{*:} For vehicles with a navigation system, refer to "Navigation System Owner's Manual".